NVR-B3211.27.50.191108 Release Notes

Zhejiang Uniview Technologies Co., Ltd.

NVR-B3211.27.50.191108 Release Notes

Keywords: Version information, usage notes, precautions.

Abstract: This document provides information about the **NVR-B3211.27.50.191108** board software, including version information, usage notes, precautions, and features.

Acronym

Acronym	Full Name	
NVR	Network Video Recorder	

2019-11-15 Page 1

Contents

1 Version Information	3
1.1 Version Number ·····	3
1.2 Applied Product Models ·····	3
1.3 Release History ·····	3
2 Usage Notes ·····	4
3 Software Features	4
4 Version Change Description ·····	4
4.1 Feature Change Description ·····	4
4.2 Operation Change Description ·····	6
5 Related Documents and Delivery Method·····	6
6 Version Upgrade Guidance ·····	6
6.1 Precautions	6
6.2 Upgrade Procedure ·····	6
6.3 Upgrade Through the System Interface ······	6
6.4 Upgrade Through the Web Interface······	7

1 Version Information

1.1 Version Number

NVR-B3211.27.50.191108

1.2 Applied Product Models

Table 1 Applied Product Models

Product Models	Description	
NVR302-08S-P8	2 slots, 8-ch, 8 PoE interfaces, H.264, H.265, 4K ultra HD.	
NVR302-16S-P8	2 slots, 16-ch, 8 PoE interfaces, H.264, H.265, 4K ultra HD.	
NVR302-16S-P16	2 slots, 16-ch, 16 PoE interfaces, H.264, H.265, 4K ultra HD.	
NVR302-09S	2 slot, 9-ch, H.264,H.265 and 4K ultra HD.	
NVR302-16S	2 slot, 16-ch, H.264,H.265 and 4K ultra HD.	

1.3 Release History

Table 2 Released Versions

Version No.	Basic Version No.	Released On
NVR-B3211.27.50.191108	NVR-B3211.27.45.191015	2019-11-08
NVR-B3211.27.45.191015	NVR-B3211.27.40.190905	2019-10-15
NVR-B3211.27.40.190905	NVR-B3211.27.35.190801	2019-09-05
NVR-B3211.27.35.190801	NVR-B3211.27.30.190712	2019-08-01
NVR-B3211.27.30.190712	NVR-B3211.27.25.190621	2019-07-12
NVR-B3211.27.25.190621	B3226P35	2019-06-21
B3226P35	B3226P30	2019-04-29
B3226P30	B3226P25	2019-04-02
B3226P25	B3226P23	2019-02-25
B3226P23	B3226P22	2018-12-26
B3226P22	B3226P11	2018-12-07
B3226P11	B3225P30	2018-10-22
B3225P30	B3225P22	2018-09-03
B3225P22	B3225P21	2018-07-26
B3225P21	B3225P10	2018-07-07
B3225P10	B3202P41	2018-05-21
B3202P41	B3202P30	2018-04-12

B3202P30	B3202P22	2018-01-04
B3202P22	B3202P21	2017-11-24
B3202P21	B3202P06	2017-11-21
B3202P06	B3202P01	2017-09-20
B3202P01	Initial release	2017-08-31

2 Usage Notes

None.

3 Software Features

Table 3 Software Features

Service	Feature	
Audio and video decoding	H.264 and H.265, 4K resolution display, up to 16Mbps bit rate.	
Data storage	Local storage of recordings in hard disk(s).	
Web-based management	Web-based user interface for device configuration and management.	

4 Version Change Description

4.1 Feature Change Description

Table 4 NVR-B3211.27.25.190621 Feature Changes

Item	Feature	Description	
	H.265	Auto switch to H.265 when first connected is enabled by default.	
	UNP client software upgrade	Upgrade UNP client software to SoftEther VPN.	
Newly added features	Live view without plug- in	Live view is available without plug-in on the Web interface.	
	LPR	Add license plate recognition display page.	
	New local interface	New local GUI; New interaction design in wizard, channel configuration, playback and VCA.	
	Retrieve password	Retrieve password by email and mobile client.	
	Preset patrol	Up to 32 presets are allowed for one preset patrol.	
Improved	Playback in main stream	Playback in standard definition automatically switches to main stream for a maximized window.	
features	Separate permissions	Separate channel live view and audio permissions.	
	Alarm configuration	Add human body detection.	
	Improve switching performance when	For connected Topsee cameras, live video starts quickly when maximizing or restoring window.	

Item	Feature	Description
	maximizing/restoring window	
	Face recognition	Support adding face snapshots to face library.
Deleted features	None	None.

Table 5 B3226P11Feature Changes

Item	Feature	Description	
	LPR	Whitelist/blacklist vehicle plate recognition.	
	Heat map	Support heatmap statistics and export.	
	GA/T1400	Upload face & plate snapshots to VMS.	
	Add device without account	Scan to add NVR on app without cloud account.	
Newly added	Onvif	Support Profile S.	
features	Pattern unlock	Support drawing pattern to unlock.	
	Alarm push notification	Push alarm notification traversing NAT.	
	Web maintenance	Add net detection & network flow.	
	Auto add IPC	Automatic search and add IPC for 1-SATA NVR with zero configuration.	
	GDPR	Add GDPR privacy statement.	
Improved live view		Configurable PTZ preset name.	
		IPC live view starts up quickly.	
Deleted features	None	None.	

Table 6 B3225P10Feature Changes

Item	Feature	Description	
	Video&Image DB (Phase 1)	Vehicle license plate recognition and search.	
New features	Alarm report	Alarm report in non-subscribe mode, with configuration added on local interface.	
	Multicast	Add uplink RTSP multicast function	
	U-Code	U-Code configuration for sub and third streams.	
	VCA alarm	Added object left behind and removal alarms	
	APP collaboration	Improves image display speed on APP.	
Improved	Playback	Supports 32x playback on VMS-B200	
features	CDN (RTMP)	Added channel-based CDN configuration	
	Prompt to change password	Added a message prompting user to change temporary password	
	Device connection	Supports adding channels in batch via RTSP	
Deleted	None None		

Ite	em	Feature	Description
featu	ires		

4.2 Operation Change Description

None

5 Related Documents and Delivery Method

Table 7 Related Document List

Manual Name	Manual Version	Delivery
Network Video Recorders Quick Guide	V1.00	Deliver with device.

6 Version Upgrade Guidance

6.1 Precautions

- This software system includes a software program mirror (Program.bin). Before you start upgrade, please back up configuration datathrough the system or Web interface in case the upgrade fails.
- Maintain proper network connection and power supply during the upgrade.

6.2 Upgrade Procedure

The version can be upgradedthrough the system interface and the Web interface, both support cloud upgrade.

6.3 Upgrade Through the System Interface

The system interface provides two options for upgrading the system software: local upgrade using a USB drive and cloud upgrade.

1. Local upgrade

Before you start, copy the correct upgrade file to the root directory of the USB drive.

- (1) Plug the USB drive into the USB interface on the NVR.
- (2) Log in to the system interface as "admin".
- (3) Click Maintain>Upgrade.
- (4) Click Upgrade, select the upgrade file from the drop-down list, and then click Upgrade. A prompt message appears.
- (5) Click OK.

Figure 1 Prompt Message



(6) The NVR will restart automatically when the upgrade is completed.

2. Cloud upgrade

Before you start, check that the NVR is correctly connected to the public network.


- (1) Click **Maintain>Upgrade**, and then click **Check** to check for the latest version.
- (2) Click **Upgrade**after a newer version is detected.

6.4 Upgrade Through the Web Interface

Perform the following steps to upgrade through the Web interface:


- (1) Log in to the Web interface as "admin".
- (2) Click Settings>Maintenance>Maintenance.

Figure 2 System Maintenance



- (3) Click **Browse** right to the **Upgrade** field, select the **Program.bin** file to upgrade, and then click **Upgrade**.
- (4) If the NVR is connected to the public network, you may also click **Check** to perform a cloud upgrade. If a newer version is detected, a prompt message will appear. Click **OK** to start upgrade.

Figure 3 Prompt Message



(5) The NVR will restart automatically when the upgrade is completed.

© 2018, Zhejiang Uniview Technologies Co., Ltd.All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without priorwritten consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.