

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for
IPC_D1202-B0007P72D1904C82

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table.....	3
1.4 Feature and Change Description	4
2 Version Upgrade Procedure	4
2.1 Upgrade Overview.....	4
2.1.1 Version Upgrade Environment.....	4
2.2 Upgrade Procedure	5
2.2.1 Upgrade Through the Web	5

1 Version Information

1.1 Version Number

IPC_D1202-B0007P72D1904C82

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_D1202-B0007P72D1904C82	IPC_D1202-B0007P62D1904C41	2021-03-11	Improved release

1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series
Series	IPC2122LR3、IPC2124LR3、IPC2125LR3、IPC2322LBR3、IPC2324LBR3、IPC322LR3、IPC3612LR3、IPC3614LR3、IPC3615LR3、IPC322SR3、IPC3232LR3、IPC3234LR3、IPC325LR3、IPC2122SR3、IPC、IPC2128LR3、SC
Models	IPC2122LR3 series: IPC2122LR3-PF40-D、IPC2122LR3-PF40M-D、IPC2122LR3-PF60M-D、IPC2122LR3-PF40M-D、IPC2122LR3-PF60M-D、IPC2122LR3-F40W-D、IPC2122LR3-PF28M-D、IPC2122LR3-S31、IPC2122LR3-S51、IPC2122LR3-S61、IPC2122LR3-S81、IPC2122LR3-M-S4、IPC2122LR3-M-S5、IPC2122LR3-M-S6
	IPC2122SR3 series: IPC2122SR3-F40W-D、
	IPC2124LR3 series: IPC2124LR3-PF40M-D、IPC2124LR3-PF60M-D、IPC2124LR3-PF28M-D、IPC2124LR3-F40W-D、IPC2124LR3-S31、IPC2124LR3-S51、IPC2124LR3-S61、IPC2124LR3-S81、IPC2124LR3-M-S4、IPC2124LR3-M-S5、IPC2124LR3-M-S6
	IPC2125LR3 series: IPC2125LR3-PF40M-D、IPC2125LR3-PF60M-D
	IPC2125LR3 series: IPC2128LR3-S31、IPC2128LR3-S51、IPC2128LR3-S61、IPC2128LR3-S81、IPC2128LR3-M-S4、IPC2128LR3-M-S5、IPC2128LR3-M-S6
	IPC2322LBR3 series: IPC2322LBR3-SP-D、IPC2322LBR3-SPZ28-D
	IPC2324LBR3 series: IPC2324LBR3-SP-D、IPC2324LBR3-SPZ28-D
	IPC322LR3 series: IPC322LR3-VSPF28-D、IPC322LR3-VSPF40-D

	IPC322LR3-VSF28W-D
	IPC3612LR3 series: IPC3612LR3-PF28-D、 IPC3612LR3-PF40-D
	IPC3614LR3 series: IPC3614LR3-PF28-D、 IPC3614LR3-PF40-D
	IPC3615LR3 series: IPC3615LR3-PF28-D、 IPC3615LR3-PF40-D
	IPC322SR3 series: IPC322SR3-VSF28W-D、 IPC322SR3-VSF28W-D
	IPC3232LR3 series: IPC3232LR3-VSP-D、 IPC3232LR3-VSPZ28-D
	IPC3234LR3 series: IPC3234LR3-VSP-D、 IPC3234LR3-VSPZ28-D
	IPC325LR3 series: IPC325LR3-VSPF28-D、 IPC325LR3-VSPF40-D
	IPC324LR3 series: IPC324LR3-VSPF28-D、 IPC324LR3-VSPF40-D
	IPC series: IPC-B114-PF28、 IPC-B114-PF40、 IPC-D114-PF28、 IPC-D114-PF40、 IPC-T114-PF28、 IPC-T114-PF40、 IPC-D112-PF28 IPC-D112-PF40、 IPC-T112-PF28、 IPC-T112-PF40、 IPC-B112-28、 IPC-B112-40 IPC-B114-28、 IPC-B114-40、 IPC-T115-PF28-M、 IPC-B124-PF28、 IPC-B124-PF40、 IPC-T124-PF28、 IPC-T124-PF40
	SC series: SC-2643F-IZS、 SC-3743F-IZS
Target file name	IPC_D1202-B0007P72D1904C82.zip

1.4 Feature and Change Description

None.


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

The screenshot displays the 'Device Maintenance' web interface with the following sections:

- Firmware Upgrade:** Contains an 'Upgrade File' text input field, a 'Browse...' button, an 'Upgrade' button, and an unchecked checkbox for 'Upgrade Boot Program'.
- Device Restart:** Features a 'Restart' button with the text 'Restart the device.' Below it, there is an unchecked checkbox for 'Enable Auto Restart', a dropdown menu set to 'Each Day', a time input field set to '02:00:00', and an 'OK' button.
- Config Management:** Includes a 'Default' button with the text 'Keep current network and user settings and restore other settings to defaults.' Below this are 'Importing' and 'Exporting' sections. The 'Importing' section has a text input field, a 'Browse...' button, and an 'Import' button. The 'Exporting' section has a text input field containing 'C:\Users\Desktop\lftp', a 'Browse...' button, and an 'Export' button.
- Diagnosis Info:** Contains a 'Storage Path' text input field with the value 'C:\Users\MyLocalFiles\Debug', a 'Browse...' button, and a 'Download' button.

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_ D1202-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.