


WI-CMS310GF | WI-CMS318GF | WI-CMS328GF

1. Packing Content




Switch x 1




Quick Installation Guide x 1



Serial Line x 1



Power Cord x 1




Mounting Accessories (hook x 2, mats x 4, screw x 8)


2. Appearance Overview

For WI-CMS310GF

• Front Panel



• Back Panel




• LED indicator and button


LED Indicator&Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
SYS	Blinking: The switch works properly Off: The switch works improperly
Link	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

For WI-CMS318GF

• Front Panel



• Back Panel




• LED indicator and button


LED Indicator&Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
SYS	Blinking: The switch works properly Off: The switch works improperly
Link/ACT	Orange on: The port is connected with 10/100Mbps speed Green on: The port is connected with 1000Mbps speed Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

For WI-CMS328GF

• Front Panel



• Back Panel




• LED indicator and button

LED Indicator&Button	Description
PWR	On: The switch is powered on Off: The switch is powered off or power supply is abnormal
SYS	Blinking: The switch works properly Off: The switch works improperly
Link/ACT	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

3. Installation

• Desktop Installation


Step1: Attach the mats to the bottom four corners of the switch.



Step2: Place the switch horizontally on the desktop.



• Rack-mount Installation




• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.
The Switch is set to DHCP by default, so it will try to obtain an IP address automatically. If that fails, then it will use the default fallback IP address, 192.168.0.1

To log in, follow these steps:

1. Launch your web browser, you type the appropriate IP address in the address bar
2. The login screen will appear. The default username and password are both admin



• Use Telnet to log in to the CLI mode of the switch

Connection Diagram:



• Use the console cable to access the switch



- Step 1 Configure the IP address of the computer and the IP address of the same segment as the switch
- Step 2 Open the cmd window of the computer
- Step 3 Enter Telnet followed by the management IP address of the switch (for example, if the management IP address of the switch is 192.168.0.1, enter Telnet 192.168.0.1)

• Desktop Installation

Step 1 Download a PuTTY software
Step 2 Use the Console cable to connect the computer and the switch as shown in the above figure

Step 3 Set the com port number of the Console line and the baud rate of the switch in the software (steps as shown in the figure below).

Note:
Step 2 is your computer recognizes the COM number of the Console line
Step 3 is the baud rate of the switch (the baud rate of the switch is 9600)



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.


• Use Telnet to log in to the CLI mode of the switch

Connection Diagram:



• Cloud login switch configuration

1. Log in to the cloud management page
(No account, you need to register an account to log in, The URL is http://cloud2.wireless-tek.com)




2. Enter the cloud binding switch

(Explain: The switch must be connected to the internet to bind successfully)




Please enter the device serial number and the last six hexes of the device MAC address to bind a device to the current group, device can be off when binding.
(Explain: The 17-digit SN code and MAC address of the switch are shown on the sticker on the back of the switch as shown in the figure below)



3. After binding, you can use the Switch in the Tunnel option in the cloud management, and then use EWEB to enter the switch.

(After entering the switch, you can configure it based on your own needs)



Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within the warranty period, we will provide professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disasters, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card loss will disqualify the product from limited warranty.



Technical Support Company Website Cloud Management

Wireless-Tek Technology Limited
Address: Building 3, Units 1801-1807, 1812, Huaqiang Era Plaza, Tangwei Community, Fuhai Street, Bao'an District, Shenzhen City, Guangdong Province, China.
Website: www.wireless-tek.com
Tel: 86-0755-32811290
Email: sales@wireless-tek.com
Technical Support: tech@wireless-tek.com

